

## HEATING CABLE

### Accessories

#### Heat Trace Accessories

*(cont'd.)*

#### LA-03, LA-10, LA-50 Ambient Sensing Heat Trace RTD 512768, 512778, 512786

LA-03 3' Long RTD w/FEP Insulation and 2" Leads (PCN 512768)

LA-10 10' Long RTD w/FEP Insulation and 2" Leads (PCN 512778)

LA-50 50' Long RTD w/FEP Insulation and 2" Leads (PCN 512786)



#### LN-03, LN-10, LN-50 Line Sensing Heat Trace RTD PCN 512794, 512807, 512815

LN-03 3' Long RTD w/FEP Insulation, flex armor, 1/2" fitting and 18" Leads (PCN 512794)

LN-10 10' Long RTD w/FEP Insulation, flex armor, 1/2" fitting and 18" Leads (PCN 512807)

LN-50 50' Long RTD w/FEP Insulation, flex armor, 1/2" fitting and 18" Leads (PCN 512815)



#### AS-BM Ambient Sensing Heat Trace RTD PCN 512823

Sensor is used for measuring the ambient air temperature. The RTD sensor element is made up with a Copper sheath and can be installed directly to a controller or junction box using the 1/2" NPT conduit fitting. The 304 SS guard protects the probe against accidental damage.



#### PS-AH Line Sensing Heat Trace RTD PCN 512831

Sensor used for measuring the surface temperature of piping of vessels. The RTD sensor element is made up with a 316 SS sheath, and with a flexible stainless steel mounting pad.



ACCESSORIES  
AND CONTROLS